



TECHNICAL BULLETIN

INSTALLATION OF OWENS CORNING® SELF-ADHERING MEMBRANES OVER FIRE-RESISTANT TREATED PLYWOOD

SUPERSEDES PREVIOUS BULLETINS

Issue Description:

Fire-Resistant Treated Plywood (FRP) is required on roofs of various commercial and multi-family residential buildings. Owens Corning does not recommend installation of our WeatherLock® or Titanium® PSU30 self-adhering underlayments over FRP. The surface of FRP products can vary widely, and we have not performed adhesion testing on all available FRP products to determine that they provide adequate adhesion. This could result in product installation or performance issues. Because of these potential issues, Owens Corning will not warrant our WeatherLock® or Titanium® PSU30 self-adhering underlayments if they are installed over FRP.

Note: This document supersedes any previous Owens Corning Technical Bulletin on this topic.

**Please contact 419-248-6557 for additional information.
Email: gettech@owenscorning.com**

Disclaimer of Liability

Technical information contained herein is furnished without charge or obligation and is given and accepted at recipient's sole risk. Because conditions of use may vary and are beyond our control, Owens Corning makes no representation about, and is not responsible or liable for the accuracy or reliability of data associated with particular uses of any product described herein.



OWENS CORNING SCIENCE AND TECHNOLOGY, LLC
ONE OWENS CORNING PARKWAY
TOLEDO, OHIO 43659
1-800-GET-PINK®
www.owenscorning.com

Pub. No. 10023713. Printed in U.S.A. August 2019. THE PINK PANTHER™ & © 1964-2019 Metro-Goldwyn-Mayer Studios Inc. All Rights Reserved. The color PINK is a registered trademark of Owens Corning. © 2019 Owens Corning. All Rights Reserved.